

# Part 573 Safety Recall Report

## 21V-003

**Manufacturer Name :** Braun Ambulances

**Submission Date :** JAN 08, 2021

**NHTSA Recall No. :** 21V-003

**Manufacturer Recall No. :** NR



### Manufacturer Information :

**Manufacturer Name :** Braun Ambulances

**Address :** 1170 Production Drive

Van Wert OH 45891

**Company phone :** 4192327020

### Population :

**Number of potentially involved :** NR

**Estimated percentage with defect :** NR

### Vehicle Information :

**Vehicle 1 :** 2019-2021 Crestline CCL150 Type III E-Series

**Vehicle Type :** BUSES, MEDIUM & HEAVY VEHICLES

**Body Style :** OTHER

**Power Train :** GAS

**Descriptive Information :** Includes all CCL 150 model vehicles produced with a CPR seat option, composed of a single side facing seating position, located on the street side of the ambulance patient compartment, with a six point belt. Vehicles not produced with the CPR seat option are not affected. 39 model year (MY) 2019 CCL150 models mounted on MY2019 Ford E-350 chassis with gas engines are affected. 7 MY2021 CCL150 models mounted on MY2021 Ford E-350 chassis with gas engines are affected.

**Production Dates :** OCT 04, 2019 - SEP 17, 2020

**VIN Range 1 : Begin :**

NR

**End :** NR

☐ Not sequential

**Vehicle 2 :** 2019-2020 Crestline CCL150 Type I F-Series

**Vehicle Type :** BUSES, MEDIUM & HEAVY VEHICLES

**Body Style :** OTHER

**Power Train :** DIESEL

**Descriptive Information :** Includes all CCL 150 model vehicles produced with a CPR seat option, composed of a single side facing seating position, located on the street side of the ambulance patient compartment, with a six point belt. Vehicles not produced with the CPR seat option are not affected. 1 model year (MY) 2019 CCL150 model mounted on MY2019 Ford F-350 chassis with diesel engine is affected. 11 MY2020 CCL150 models mounted on MY2020 Ford F-350 chassis with diesel engines are affected.

**Production Dates :** MAY 20, 2020 - OCT 28, 2020

**VIN Range 1 : Begin :**

NR

**End :** NR

☐ Not sequential

Vehicle 3 : 2019-2020 Crestline CCL150 Type III G-Series  
 Vehicle Type : BUSES, MEDIUM & HEAVY VEHICLES  
 Body Style : OTHER  
 Power Train : GAS

Descriptive Information : Includes all CCL 150 model vehicles produced with a CPR seat option, composed of a single side facing seating position, located on the street side of the ambulance patient compartment, with a six point belt. Vehicles not produced with the CPR seat option are not affected. 1 model year (MY) 2019 CCL150 models mounted on MY2019 Chevrolet G3500 chassis with gas engine is affected. 2 MY202 CCL150 models mounted on MY2020 Chevrolet G3500 chassis with gas engines are affected.

Production Dates : APR 09, 2020 - OCT 28, 2020

VIN Range 1 : Begin :

NR

End : NR

☐ Not sequential

## Description of Defect :

Description of the Defect : The defect concerns two of the eight fastening points of the seat belt system installed in the ambulance patient compartment side-facing CPR seating position on the street-side of the vehicle. There exists a potential that two of the threaded inserts used for the rearward retractor and shoulder belt D-ring are installed too close to a mounting flange resulting in improper crimping of the threaded insert.

FMVSS 1 : NR

FMVSS 2 : NR

Description of the Safety Risk : Continued use of the affected seating system may result in partial or complete loss of effectiveness of the seat belt harness which may increase the chance of injury to the occupant, in that seated position, in the event of a crash.

Description of the Cause : NR

Identification of Any Warning : A loose retractor mounting bolt or shoulder belt D-ring bolt can serve as a that can Occur : visible warning for this condition.

## Involved Components :

Component Name 1 : NR

Component Description : NR

Component Part Number : NR

**Supplier Identification :****Component Manufacturer**

Name : NR

Address : NR

NR

Country : NR

**Chronology :**

NR

**Description of Remedy :**

Description of Remedy Program : NR

How Remedy Component Differs NR  
from Recalled Component :

Identify How/When Recall Condition NR  
was Corrected in Production :

**Recall Schedule :**

Description of Recall Schedule : NR

Planned Dealer Notification Date : NR - NR

Planned Owner Notification Date : NR - NR

\* NR - Not Reported